## AX-CTX10

## AC current transmitter - voltage output



#### **Product overview**

The AX-CTX10 Voltage Output Analog Current transmitters are designed for use in any AC current monitoring application in which you are looking to monitor a particular piece of equipment for proper operation. It uses an "Average" current measuring method and should be used in applications where a pure Sinusoidal AC waveform that has very little or no distortion/noise on the conductor being monitored. Applications may include monitoring a resistive type load such as an incandescent light bulb or heating element as well as any single-speed linear load.



### **Products Features**

- No external supply voltage required
- Multiple selectable ranges

- Cost-effective
- Din rail mountable

## **Product Specifications**

Monitored current type:

Maximum AC voltage:

Isolation voltage:

Operating frequency:

AC

600Vac

2200Vac

50 to 600 Hz

Core style: Solid core

Supply voltage: Induced from monitored conductor (Insulated conductors only)

Sensor Amperage Range: Field selectable. (see order codes)
Output signal: 0-10VDC (Min 10KOhm load)

Response time: <300 ms

Accuracy: +/- 1% from 5-100% of selected range

Electrical connections: 2 way screw terminal block (Polarity Sensitive)

Wire size: 18 to 24 AWG (0.823 mm2 to 0.205 mm2) Copper Wires only

Aperture size: 19.05 mm (0.75")

Din rail size: 35mm

Ambient temperature/humidity: -15°C to 40°C / 0-95% RH non-condensing

Storage temperature/humidity: 5°C to 35°C / 40% to 80% RH non-condensing

Enclosure material: PC/ABS (Polycarbonate/ABS Blend)

Flammability rating: UL94-V0

Agency Approvals: UL/CUL US Listed (UL 508) Ind. Control Equipment , CE, RoHS2, WEEE

Dimensions/Weight: 70.11 mmx 84.92 mm x 26.67 mm / 90gms

Country of origin: USA

### **Order Codes**

Part number Description


AX-CTX10-50 AC current transmitter, 0-10V output, 0 to 10/20/50A AX-CTX10-150 AC current transmitter, 0-10V output, 0 to 50/100/150A

# AX-CTX10

## AC current transmitter - voltage output



### **Dimensions**




### **Installation**

The unit should be installed by a suitably qualified technician in accordance with prevailing regulations and any guidelines for the equipment to which it is to be connected.

Maintain a minimum distance of 26 mm between the current sensor and other magnetic devices like contactors, relays, transformers etc.

## **Typical wiring**



As a general rule screened cable should be used to connect signal to a BMS or other controller. The shield should be connected to the earth at one end only.

### **Datasheet Contents**

Every effort has been taken in the production of this data sheet to ensure accuracy. Annicom do not accept responsibility for any damage, expense, injury, loss or consequential loss resulting from any errors or omissions. Annicom has a policy of continuous improvement and reserves the right to change this specification without notice.