AX-OC-WMW

Wall mount microwave occupancy sensor



Product Overview

The AX-OC-WMW range of occupancy sensors are designed for use in energy savings systems where the lighting loads are automatically controlled based on occupancy. There is an adjustable timer that switches off the load when the area is no longer occupied. The built-in daylight sensor aids additional energy savings in lighting control applications. The device will turn on the load only if the ambient light is below a preset level.

The unit is mounted on a single gang plate for easy installation.



Products Features

- 10.525GHz microwave sensor
- 20 metres detection range
- 230Vac and 24V versions available

- Excellent EMI immunity
- Built-in light sensor
- Touch switch to override the sensor (optional)

Product Specifications

Power supply: $230 \text{ Vac} \pm 10 \% 230 \text{V} \text{ versions}$

 $24 \text{ Vac/dc} \pm 10 \%$ for 24 V versions

Power consumption: 1W maximum

Sensor type: Microwave, 10.525 GHz

Antenna 3dB beam width: Horizontal: 72°, Vertical: 36°

Detection range: Up to 20m

Output: Supply voltage for switched live versions. SPST for volt free versions

Terminals: Rising clamp for 0.5-2.5mm2 cable

Contact rating: 6A @ 240Vac resistive

Timer adjustability: 10 secs to 12 mins

Daylight sensor lux threshold: 0-1000lux.(Can be disabled with jumper)

Ambient temperature range: 0°C to $+50^{\circ}\text{C}$

Front plate material: Flame retardant ABS

Dimensions: 85 x 85 x 35 mm

Backbox depth: Minimum 26mm

Conformity: EMC:2004/108/EC,LVD:2006/95/EC

Weight: 160gms Country of origin: UK

Product Order Codes


Switched live	Volt free	Description
AX-OC-WMW-24SL	AX-OC-WMW-24VF	Wall mount microwave occupancy sensor, 24V
AX-OC-WMW-230SL	AX-OC-WMW-230VF	Wall mount microwave occupancy sensor, 230V

Add -O for optional touch switch for overriding sensor

AX-OC-WMW

Wall mount microwave occupancy sensor





Installation

The AX-OC-WMW should be installed by a suitably qualified technician in conjunction with any guidelines for the equipment it is to be connected to and any local regulations.

Adhere to the following guidelines for the proper operation of the product.

- Switch off the power to the unit before performing any work on it.
- Do not position sensor on a vibrating surface.
- Site as far away as possible from metal objects.
- Do not exceed the rated loads. This could lead to contact welding.
- At maximum sensitivity, the unit may detect movements through thin walls or partitions. Reduce sensitivity if necessary

Operation

It uses doppler effect to find movements within its range. A 10.525GHz built-in transceiver transmits the high frequency electromagnetic wave and receives the signals reflected off objects in its path. Any movement will create frequency shifts in the received signal. This data is processed with help of a microcontroller to determine whether a movement is detected or not and control the connected load.

The 'LUX' preset sets the ambient light threshold below which the output will be ON when the sensor detects a motion. When movement stops, the device will turn off the output after a time period set by the 'TIMER' preset. Touch switch on the front side allows the user to override the sensor and manually turn on and off the output.

Unit will be in 'AUTO' mode when it is powered up. Touch the switch to override the sensors and turn ON the relay. Touch again to turn OFF the relay.

The LED will light up or blink when the unit detects motion or change status.

Blinking Green LED - Motion detected in AUTO mode. Relay is ON.


Blinking Red LED - Motion not detected in AUTO mode. Relay is OFF.

Constant green LED - (- O versions only) Relay is ON.

Constant Red LED - (- O versions only) Relay is OFF.

Alternating green and red - Sensor Error

LUX sensor can be disabled using the onboard jumper. Once disabled, the unit will switch ON and OFF based on motion detection only.



LT - Lux threshold set by LUX preset


T - Timer period set by TIMER preset

AX-OC-WMW


Wall mount microwave occupancy sensor



Connections



Typical Wiring Diagrams



Datasheet Contents

Every effort has been taken in the production of this data sheet to ensure accuracy. Annicom do not accept responsibility for any damage, expense, injury, loss or consequential loss resulting from any errors or omissions. Annicom has a policy of continuous improvement and reserves the right to change this specification without notice.