ESC-RM1Single Relay Module - Single Pole





Product Overview

The ESC-RM1 is a SPDT relay module. The units are available with a number of different coil options including the ESC-RM1-12DC sensitive coil version to reduce the load on BMS controllers such as Trend outstations. The ESC-RM1-24AC can be used for converting a triac digital output to a VFC and the ESC-RM1-24DC for switching loads on controllers with 24Vdc powered digital outputs.

Features

- Large Range of Coil Options
- Optional diode and LED modules available please enquire
- Assembled on DIN rail carrier, with retaining clip
- Sensitive coil 12Vdc version can convert BMS Outputs to VFC

Product Specifications

Coil Rating: ESC-RM1-12DC 12Vdc - 20.8mA (sensitive coil), will switch on at 9.0V

ESC-RM1-24AC 24Vac - 31.6mA ESC-RM1-24DC 24Vdc - 16.7mA ESC-RM1-230AC 230Vac - 3.2mA

Contact Rating: ESC-RM1-12DC SPDT - 250V @ 10A (Resistive)

ESC-RM1-24AC SPDT - 250V @ 12A (Resistive)
ESC-RM1-24DC SPDT - 250V @ 12A (Resistive)
ESC-RM1-230AC SPDT - 250V @ 12A (Resistive)

Dielectric Strength: 5000Vrms coil to contacts

Contact Material: AgNi 90/10

Terminals: Rising Clamp for 0.5-2.5mm² cable

Ambient Temperature Range: -25°C to 85°C

Dimensions: 77 x 15.5 x 69mm (max.)

Country of Origin: United Kingdom

Order Codes

ESC-RM1-12DC Single Relay Module 12Vdc sensitive coil

ESC-RM1-24AC Single Relay Module 24Vac Coil ESC-RM1-24DC Single Relay Module 24Vdc Coil ESC-RM1-230AC Single Relay Module 230Vac Coil

© Copyright Annicom. All Rights Reserved

ESC-RM1

Single Relay Module - Single Pole



Installation

The ESC-RM1 should be installed by a suitably qualified technician in conjunction with any guidelines for the equipment which it is to connected to. Field wiring should be installed to satisfy the requirements set out by the manufacturer of the equipment that the module is being connected to using screened cabled where necessary.


WARNING

The ESC-RM1 is designed to switch mains voltage and therefore dangerous voltages may be present on the module. Ensure that the power is isolated before working on this module.


The ESC-RM1 would typically be located within the controller section of a BMS control panel. The module can be snapped on to standard "top hat" profile DIN rail by levering the clip downwards to allow the unit to locate without the need for excessive force.

These modules are supplied as an assembled relay, DIN rail base and clip. These parts are assembled at the Annicom factory in the UK. Annicom reserve the right to supply these modules using various manufacturers relays and bases. As such, the relay and base may show other manufacturers logos and pat numbers.

Description and Connections



Dimensions



Datasheet Contents

Every effort has been taken in the production of this data sheet to ensure accuracy. Axio do not accept responsibility for any damage, expense, injury, loss or consequential loss resulting from any errors or omissions. Axio has a policy of continuous improvement and reserves the right to change this specification without notice.