# **AX-HMH Electromechanical Humidistat**





### **Product Overview**

Humidistat, 1, 2 step or proportional, for duct or wall mounting

AX-HMH / AX-HPH is a series of electromechanical humidistats for control of humidifying and/or dehumidifying in HVAC systems.

# **Products Features**

- One or two steps
- Change-over contact, 250VAC 10 A
- Proportional output 148 or 1000 Ohms.

## **Product Specifications**

- Excellent accuracy and reliability
- For duct or wall mounting
- Protection class IP54

r roudot opoonnoutione	
Relay Contact Data	10 A, 250 VAC resistive at 25°C ambient
	8 A, 250 VAC resistive at 60°C ambient
	Not suitable for DC circuits
Material	Housing: Extruded aluminium (brown)
	Plastic components: Self-extinguishing Macrolon (white).
Ambient Temperature	Sensor -2070°C
	Housing -2060°C
Mounting	Via universal bracket, for both wall or duct mounting
Cable Gland	PG11
Weight	0.6 kg
Protection Class	IP54
CE	Low Voltage Directive (LVD) standards: This product conforms to the requirements of the European Low Voltage Directive (LVD) 2006/95/EC through product standards EN 60730-1 and EN 60730-2-13.
	EMC emissions & immunity standards: This product conforms to the requirements of the EMC Directive 2004/108/EC through product standards EN 61000-6-3.
	RoHS: This product conforms with the Directive 2011/65/EU of the European Parliament and of the Council.
Setpoint	10100%RH
Hysteresis	3%RH at 45%RH
Step Differential (AX-HMH2)	025%RH at 45%RH
Proportional Band (AX-HPH148, AX-HPH1000)	7%RH

# **Product Order Codes**

Issue 1.0

AX-HMH	1 step, change-over contact humidistat
AX-HMH2	2 step, change-over contacts humidistat
AX-HPH148	Proportional, 0-148 Ohm humidistat
AX-HPH1000	Proportional, 0-1000 Ohm humidistat

ANNICOM Ltd Unit 21, Highview, High Street, Bordon, Hampshire, GU35 0AX



#### Construction

The humidistat utilises human hair as its sensor medium. The hair stretches as the humidity increases and shrinks as the humidity decreases. These changes are then transmitted to a micro switch (or, optionally, to two switches). In case of the AX-HPH, the changes are transmitted to a pin on a potentiometer.

The setpoint switch affects the position of the micro switches in relation to the hair element. The setpoint can be set at between 10 and 100% RH.

As the contacts are of the change-over type, the humidistat can control both humidification and dehumidification. This tried and tested construction, employing only a few movable parts, offers a high degree of reliability and accuracy.

#### 2 Step Humidistat

This model has two micro switches. The step differential between them can be set by means of an adjustment screw. As the contacts are of the change-over type, the humidistat can control both humidification and dehumidification.

#### **Proportional Humidistat**

AX-HPH148 and AX-HPH1000 are humidistats with proportional resistance output.

Depending on the setpoint chosen and the current

humidity, these give output signals of 0 to 148 Ohms and 0 to 1000 Ohms for control of installations intended for this type of signal.

#### Mounting

AX-HMH/AX-HMH2/AX-HPH can be mounted in a ventilation duct or on a wall. The humidistat comes supplied with a flange which makes it suitable for both positions.

### Calibration

The humidistats are calibrated at the factory before delivery to the customer, but should be precision calibrated after installation to ensure optimal results. After this, annual checks and re-calibration are recommended.

#### Maintenance

The hair element should be dusted off with a soft brush once a year. Do not rinse the hair element in water as this changes the calibration point.

For further information concerning maintenance, see instructions supplied on delivery.

#### **Typical Applications**

Can be used to control a humidifier or a dehumidifier or for on/off controlling of a fan. Can also be used to alarm when the humidity exceeds or falls below a pre-set level.




The contact between terminals 1 and 2 closes when the humidity exceeds the setpoint value.

AX-HMH2		
1		
2		
3		
4		
5		
6		

On the AX-HMH2, the contact between terminals 1 and 3 closes when the humidity exceeds the setpoint value. When humidity continues to rise and exceeds the setpoint value for step 2, the contact will close mellan terminals 4 and 6.



As the humidity increases, resistance between terminals 1 and 3 will increase as resistance between terminals 1 and 2 will decrease.



# **Datasheet Contents**

Every effort has been taken in the production of this data sheet to ensure accuracy. Annicom do not accept responsibility for any damage, expense, injury, loss or consequential loss resulting from any errors or omissions. Annicom has a policy of continuous improvement and reserves the right to change this specification without notice.